




GEOLOCATION

INSTRUCTIONS FOR USE




1 Connection / start-up / shut-down



- ✓ **1/ CONNECT** the USB cable to your car's USB port and the USB-C part to the tracker.
- ✓ **2/ INSTALL** the tracker
 - >> Recce: install the tracker in the cockpit
 - >> Rally: fix the tracker to the roll bar with clamps (according to installation instructions)
- ✓ **3/ tracker START-UP**
Press the On/Off button for more than 2 seconds. The screen lights up on the Home screen.
 - >> Recce: launch Reco Mode 
 - >> Rally: launch Izi Race FFSA 
- ✓ **4/ STOP tracker (only applies to Recce)** : press and hold the On/Off button for more than 2 seconds. A stop confirmation will appear on the screen, click and confirm.




IMPORTANT: The On/Off button is the one located on the right-hand side in the center of the tracker.

NOTE: press the green (on/off) button 2 times consecutively to restart the display. 

2 USE IN RECCE



Zone with no speed limit declared by the organizer. In this case, please respect traffic regulations.



Zone with speed limit declared by the organizer.

In this mode, no interaction is possible.

Instantaneous speed display


When you exceed the speed limit in a sensitive area declared by the organizer, an audible signal and a specific display will appear.

3

RACING USE



After initiating its start-up process, the interactive tracker will automatically arrive on the home screen.
Launch iZi Race FFSA.



White light

Race number

Report button

Messages from Race HQ

SOS button
Emergency phone call



In case of stop in ES, crew ok



In case of a stop in ES, with a request for assistance

 +  = The car does not interfere with ES.

 +  = the car blocks ES.

 +  = The crew requests medical intervention.

 +  = An intervention for fire is requested.

When the SOS Medical and Fire buttons are pressed, the tracker automatically calls the Rally HQ.




Message sent

IMPORTANT: If "Message Sent" does not appear in the "Message from Race HQ" field after triggering an OK or SOS alert, the message will not be received by Rally HQ. If the message does not appear, trigger the alert again.



RALLY HQ MESSAGES




You can receive text messages from Rally HQ at any time.

You must confirm receipt of the message by pressing "CONFIRM ».



RALLY HQ CALL



Rally HQ can call you if they don't hear from you while you're stopped in an ES.

In exceptional cases and with authorization (tel. 07 68 88 27 57 - 06 95 64 61 76), the Interactive Tracker must be returned the day after the rally.

By post to VDS RACING - 6 place du Comte Raymond VI 30650 Rochefort du Gard